


Dear users, please read this guide carefully before you use KT-LED880 instrument. The manual will guide you use the instrument correctly to achieve a variety of vehicle control and vehicle status displays.

Functions and Display




1	Operation button	ON/OFF button	3	Battery capacity indicator	4 LED indicator
2		MODE button	4	Power ratio gear	Gear 3 LED indicator

Operation

1. ON/OFF


Hold **ON/OFF** button long to startup; hold **ON/OFF** button long for a second time to turn off the meter. When the motor stops driving and when the meter is not used for a consecutive 5 minutes, it will automatically shut down and turn off the motor power supply.

2. Boot display interface




Hold **ON/OFF** button long to startup and enter boot display interface.

2.1 Assist ratio gear switch



Hold **MODE** button shortly to switch 1-3 file gear, LOW is for the minimum power gear, MED is for the middle power gear, and HIGH is for the highest power gear. Each startup will automatically restore the gear shutdown last time.


2.2 Power Display



When battery power capacity is greater than 80%, all 4 LED indicator are lit. When the battery capacities drop, the indicators are off in order. When the power capacity is less than 20%, the last indicator is flashing (L side). When the controller is under-voltage protection, all 4 LED indicators are power off, which means that the vehicle is currently shutdown due to low voltage.


2.3 Startup headlights

Optional 1




Hold **MODE** button long to startup the lights (the controller should have the function of headlight driving output or built-in meter headlight driving output function), Hold **MODE** button again to turn off vehicle headlights.

Optional 2




Hold **MODE** button long to startup the lights (the controller should have the function of headlight driving output or built-in meter headlight driving output function), **LIGHT** indicator lights. Hold **MODE** button again to turn off vehicle headlights, and the **LIGHT** indicator is turned off.

Optional 3



Hold **LIGHT** button shortly to startup the lights (the controller should have the function of headlight driving output or built-in meter headlight driving output function), **LIGHT** indicator lights. Hold **LIGHT** button again to turn off vehicle headlights, and the **LIGHT** indicator is turned off.


2.4 6KM/H boost function (Optional)



Hold **6KM/H** button and LED indicator flashes, the vehicle drives at the speed should be no more than 6Km/h. Release **6KM/H** button, the function is invalid.

Outlook and Size

1. Meter dimension



2. Wiring schematic

